



BKR-MCP

REPLACEMENT MICROPHONE CONNECTING PROCEDURE TO SELECT BECKER HANDS-FREE RADIOS

The BKR-MCP aftermarket replacement microphone works on select Becker Bluetooth Hands-free radios with 2-pin micro-fit socket including Indianapolis Pro, Grand Prix etc. Becker radios with 8-pin ISO socket requires our [BKR-MC](#)

Warning: The 2-pin microphone input on Cascade radios can only be used for built-in hands-free operation. External hands-free kits must use their own microphone or purchase an adapter (e.g., [BKR-MR2](#))

Package contents:

- Microphone with 10 ft. cable x 1
- U-shape bracket with self-adhesive backing x1
- 2-pin micro-fit plug x 1

Installation:

Remove radio. Click [here](#) for radio removal guide.




Fig. 1

Microphone should be placed to allow for optimum voice recognition. Recommended positions can be seen in **Fig. 1**
A (visor) **B** (pillar)

Insert cable 2-pin micro-fit plug to radio microphone socket (release tap facing up) See **Fig. 2**




Fig. 2